
SKILL - Cadence Extension Language

- *SKILL* is powerful extension language that can be used to add new capabilities to Cadence tools
- SKILL is based upon LISP, will look very strange if you are not already familiar with LISP
 - LISP is a interpreted language that is popular among the AI community
 - LISP has a built-in eval function that can be used to execute LISP code that is dynamically generated
 - The basic data structure in LISP is the list, with many built-in functions for manipulaing list data structures
 - SKILL also supports a syntax form that is more 'Pascal'-like
- The key to SKILL's power is a large set of library functions that allow you to manipulate data structures such as cells, nets, mask information, etc.

BR 6/00

To Get Help On Skill

• To get help on SKILL, click on the Help menu from within the Cadence layout editor, then on "*Openbook Main Menu*". Choose the 'SKILL and SKILL PI to open the Skill documentation.



BR 6/00

2

A Sample SKILL Function

This SKILL function will create a padframe with X number of pads per side:

BR 6/00

SKILL function (cont)

```
(for i 1 no_pads
   (dbCreateInst (getEditRep) (dbOpenCellViewByType "tutorial"
"PADNC" "layout") nil (list xpointv ypointv-90) "R90")
   (dbCreateInst (getEditRep) (dbOpenCellViewByType "tutorial"
"PADNC" "layout") nil (list xpointv+no_pads*90 ypointv) "R270")
        (setq ypointv ypointv+90)
        )
   (dbCreateInst (getEditRep) (dbOpenCellViewByType "tutorial" "PADFC"
"layout") nil (list xpointv-300 ypointv-90) "R0")
   (dbCreateInst (getEditRep) (dbOpenCellViewByType "tutorial" "PADFC"
"layout") nil (list xpointh-90 ypointv+210) "R270")
   (dbCreateInst (getEditRep) (dbOpenCellViewByType "tutorial" "PADFC"
"layout") nil (list xpointh+210 201) "R180")
   (dbCreateInst (getEditRep) (dbOpenCellViewByType "tutorial" "PADFC"
"layout") nil (list 201 -99) "R90")
)
```

BR 6/00 4

Comments on SKILL function

- Contained in file called 'pads.il'
 - To load function, in icfb command line type "load pads.il"
 - To execute function, have a layout view open and type "placePadFrame 10" if you want 10 pads per side
- Uses the *dbCreateInst* function for instance creation
 - Documented in DFII SKILL Functions Reference
- Function parameters are:
 - d cellview cellview where instance is placed
 - d master master cell view of the instance to be created
 - t_name instance name. If 'nil' is used, then generate an instance name
 - 1 point origin of new instance as 2-element list
 - orientation of new instance as a string, some possible strings are "R0", "R90", "R180", "R270"

BR 6/00 5

dbCreateInst

- The function *getEditRep* was used to return the currently open cell view
- The function *dbOpenCellViewByType* was used to specify the master view of the instance to be placed.
 - The minimum set of parameters to dbOpenCellViewByType are library_name, cell_name, view_name
 - See docs for other optional parameters
- The *list* function used to create a list required to pass instance origin
 - (list first elem second elem .. N elem) returns a N-element list

BR 6/00 6

Creating an Rows x Cols Array of Instances

Tested with standard cell instance via: placeArray 20 4 "INVX1" 4.8 21.6

BR 6/00

